

NISSAN SUNNY (1991 to 1995)

How To Remove a Nissan Sunny Car Stereo (1991 to 1995)

Tools Required

Screwdriver

OEM Stereo Image:



Comments:

Nice and easy

Step 1

Start by undoing the screws around the dash display console.



Step 2

There are also 3 screws under the center console on one side of the steering wheel and another 2 screws on the other side. Undo these.





Step 3

The handbrake surround should also just clip off allowing you to remove another 2 screws at the bottom of the center console.



Step 4

Now remove the lower part of the console to reveal another final 2 screws holding the radio surround in place.



Step 5

Now remove the console from around the radio to reveal the screws holding the stereo in place.



Step 6

Remove radio and disconnect aerial and ISO wiring plugs from back.

All tutorials are copyright www.fitaudio.com 2007 - Ask permission before replicating any of this information.